

Supervision : User Guide

Edge Airport France





Table of Contents

Supervision : User Guide
Introduction
Objective
Description of the user interface
Viewing the display devices
Displaying device content
Removing screensMosaic
Managing zones
Turning on devices within a zone
Restarting devices in a zone
Switching off devices in a zone
Adding the area
Creating a parent area
Creating a child area
Changing the placement of a zone
Managing the devices
Turning on A device
Restarting a device
turning off a device
Viewing display of the devices
programming on/off times of samsung soc screens
Adding a device
Adding a samsung soc screen
Adding a computer
CHANGING THE DEVICE
Deleting a device
Edge Airport France



Supervision : User Guide

×

Introduction

Objective

Edge Supervision allows real-time visualization of what is being displayed on the screen allowing you to supervise all of the workstations and the display systems. This mosaic, fully configurable, allows users to view live all the connected PCs and screens and set the thumbnail view to regroup stations by function, location, type. It is also possible to take control of each screen remotely, independently of the others, in order to perform a manual action if necessary.



Description of the user interface



- All actions are possible
- 2 actions are possible: Power Off and Edit Schedule
- Only 1 action is possible: Power On

Viewing the display devices

Displaying device content

• Click Show All on the menu bar.



A mosaic of contents appears on the screen.





Removing screensMosaic

• Click Hide All on the menu.



Managing zones

Turning on devices within a zone

- Right click on the name of the zone to be switched on.
- Position the mouse on Remote Client Actions.
- Click on Power on in the context menu.



Restarting devices in a zone

- Right-click on the name of the zone to be restarted.
- Position the mouse on Remote Client Actions in the menu which appears
- Click on Restart in the context menu.



Switching off devices in a zone

- Right-click on the name of the zone to be switched off.
- Position the mouse on Remote Client Actions.
- Click on Power off in the context menu.



Adding the area

- Right-click in the screen area.
- Click on Add Area in the menu that appears.





• Enter name for a new zone in the Name field of the **Dialog** window.



Creating a parent area

• Click on/in the Dialog window:



• Click on OK to confirm.

Creating a child area

A child area is a zone that is dependent on another zone.

• Click on one of the existing zones.



• Click on OK to confirm.

Changing the placement of a zone

- Right-click in the area you want to change.
- Click Edit Area in the context menu.



• The **Dialog** window opens:



- Type the new name of the zone in the Name field.
- Click on the Parent Area dropdown arrow to change its location.
- Click OK to confirm.



Managing the devices

Turning on A device

- Right-click on the device to be switched on.
- Position the mouse on Remote Client Actions.
- Click Power on in the context menu.

Chip Inprotein - d		2 P 2 8 1
under and and a second and a se		
E Armote Clearta		
has a 2		
W down transfing international O IX II		
r Gesk h		
State Part of the		
Con 743 - Con 74		
Constant and a Description		
Constant Constant		
and and a share		
 Approximation and Approximation and		
And And And The Address		
Souther and the second se		
• costes=1		
 transferiction Antician 		
· free dealers, · · · · · · · · · · · · · · · · · · ·		
· amputer Estate Test		
Restantions: R.B. B.		
Contractments 0 10 4		
4 Transp Manufaced		
There have been been the set of t		
🗰 from hong-international i 😝 DK - D		
- National Advances of the Second Sec		
The state at the second s		
• cos setas • • • • •		_
		-
jas Becelol ese, juĝi especielloj la altivanos anala deviando anal.		
(3) (2) (4) (3) (4) (3)	5 6 6 6 6 6 6 F F F F	1140 10

Restarting a device

- Right-click on the device to be restarted.
- Position the mouse on Remote Client Actions in the menu which appears
- Click on Restart in the context menu.



turning off a device

- Right-click on the device to be switched off.
- Position the mouse on Remote Client Actions in the menu which appears.
- Click on Power off in the context menu.

Aller Specifier - d	1010 8.8
E Remote Clearts	
tana a la	
The first hardwards of the first state of the first	
· Ganta is	
And Address of the	
Con Party - Konce Case Force - Price P	
Store destrict Barbidge 20 Patient	
The day of the law of	
 and data of the second s	
E destalation	
ALLAND DE COLONIA	
Concerned B. Lines	
and day by R. Secondary	
Concrete Con	
Antipation Antipation	
Annu America III Annual	
Invitation Invitation	
Construction of the second sec	
1 isang Remote	
🗰 disar kang banakat 🛛 😯 18 🛛 👘	
Contraction (1) U IN -0	
 Transplationships 	
for hop intention: W K E	
The surpression of the second se	
A CONTRACT OF A	
an Be-piljol eans (gél-resarcholar) is altiteiren erste derlander eran	
	The second se

Viewing display of the devices

1. Click on the relevant device.

×

- 1. Click Show / Hide in the menu bar.
- 2. The contents are displayed.

×

programming on/off times of samsung soc screens

1. Right click on the device to be programmed.



- Position the mouse on Remote Client Actions in the menu which appears.
- 3. Click on Edit Schedule in the contextual menu.
- 4. The Edit Schedule window opens.
- 5. Check mark the Power On to set the time at which the device should turn on.



- 6. Fill out the fields below.
- 7. Check mark the Power Off box to set the time at which the device should turn off.
- 8. Fill out the fields below.
- 9. Click OK to confirm.

Adding a device

- 1. Right-click on the screen area.
- 2. Click on Add Client in the menu that appears.
- 3. The Select a Remote Client window opens:

×

Adding a samsung soc screen

1. Click on SoC Samsung in the Select a Remote Client window.

×

1. The Remote Client window opens:

×

- 1. Complete the fields.
- 2. Click OK to confirm.

Adding a computer

1. Click on VncComputer in Select a Remote Client window.

×

- 1. Click on OK.
- 2. The Dialog window opens :

×

- 1. Complete the fields.
- 2. Click OK to confirm.

CHANGING THE DEVICE

- 1. Right click on the device to be edited.
- 2. 🗵 Click on Edit Client in the menu which appears.
- 3. The Remote Client window opens :

- 1. Modify the necessary fields.
- 2. Click OK to confirm.

Deleting a device

- 1. Right-click on the screen area.
- 2. Click on Remove Client in the menu which appears.

= End of the user manual. =

From: https://edgeairport.alwaysdata.net/wiki/ - Documentation Embross (ex Edge Airport)

Permanent link: https://edgeairport.alwaysdata.net/wiki/doku.php?id=en:guides:utilisation:supervision&rev=1490793649

Last update: 29/03/2017 15:20



Edge Airport France

Airport Manager Solutions

Phone: +33 553 801 366

Service commercial : contact@edge-airport.com

Support technique : support@edge-airport.com

Edge Airport France SAS au capital de 150 000 €

RCS Bergerac 529 125 346 Les Lèches TVA : FR53529125346 / EORI : FR52912534600039

Tel: +33(0)553 801 366 contact@edge-airport.com www.edge-airport.com