

FAQ FiDS : Ecran qui redémarre tout le temps

Edge Airport France



Edge Airport France 17/11/2025 11:00 /



FAQ FiDS: Ecran qui redémarre tout le temps

Table des matières

FAQ FiDS : Ecran qui redémarre tout le temps	
Edge Airport France	

Edge Airport France 17/11/2025 11:00 /



FAQ FiDS : Ecran qui redémarre tout le temps



Il peut y avoir 2 raisons possibles :

- 1. L'écran n'est plus connecté au réseau :
 - Vérifier le câble RJ45
 - S'assurer que l'écran est bien visible depuis le réseau.
- 1. L'écran est resté en mode <S> qui veut dire Stop ou Shutdown :
 - Lancer FIDS Menu depuis un poste de travail
 - Changer le mode d'affichage de l'écran (par exemple, le mettre en veille).
 - Eventuellement, sélectionner l'écran
 - Faire un clic droit dessus.
 - Cliquer sur l'option "Allumer le ou les écrans sélectionnés".

From:

https://edgeairport.alwaysdata.net/wiki/ - Documentation Embross (ex Edge Airport)

Permanent link:

×

https://edgeairport.alwaysdata.net/wiki/doku.php?id=faq:fids:rebootecran&rev=1538033485

Last update: 27/09/2018 09:31

Edge Airport France 17/11/2025 11:00 1/2

Edge Airport France

Airport Manager Solutions

Phone: +33 553 801 366

Service commercial : contact@edge-airport.com

Support technique: support@edge-airport.com

Edge Airport France SAS au capital de 150 000 €

RCS Bergerac 529 125 346 Les Lèches TVA: FR53529125346 / EORI: FR52912534600039

Tel: +33(0)553 801 366 contact@edge-airport.com www.edge-airport.com

Edge Airport France 17/11/2025 11:00 2/2