FAQ FiDS : Ecran qui redémarre tout le temps

Edge Airport France

Table des matières

FAQ FiDS : Ecran qui redémarre tout le temps .....
Edge Airport France .....

FAQ FiDS : Ecran qui redémarre tout le temps



Il peut y avoir 2 raisons possibles :

1. L'écran n'est plus connecté au réseau :
    - Vérifier le câble RJ45
    - S'assurer que l'écran est bien visible depuis le réseau.

1. L'écran est resté en mode <S> qui veut dire Stop ou Shutdown :
    - Lancer FIDS Menu depuis un poste de travail
    - Changer le mode d'affichage de l'écran (par exemple, le mettre en veille).
    - Eventuellement, sélectionner l'écran
    - Faire un clic droit dessus.
    - Cliquer sur l'option “Allumer le ou les écrans sélectionnés”.

From:
https://edgeairport.alwaysdata.net/wiki/ - **Documentation Embross (ex Edge Airport)**

Permanent link:
https://edgeairport.alwaysdata.net/wiki/doku.php?id=faq:fids:rebootecran&rev=1538033485

Last update: **27/09/2018 09:31**

Edge Airport France

Airport Manager Solutions

Phone: +33 553 801 366

Service commercial : contact@edge-airport.com

Support technique : support@edge-airport.com

Edge Airport France SAS au capital de 150 000 €

RCS Bergerac 529 125 346 Les Lèches TVA : FR53529125346 / EORI : FR52912534600039

Tel : +33(0)553 801 366 contact@edge-airport.com www.edge-airport.com